

Processing instructions

Material- and working- temperature: between 18 - 25 °C.

Close containers after use.

Seal porous mould surfaces first (**ebalta** mould sealer).

For optimum mould releasing we recommend a special release agent (like T1-1), which can be applied easily with a brush or be sprayed. Releasing of the mould 2-3 times, evaporate for about 20 min. after each releasing.

Mixing ratio resin/hardener according to instructions.

Stirring rods etc. with residual resin can be easily cleaned with **ebalta** cleaning agent.

In General

The product is a Polyurethane system.

The casting resin can be accelerated on request.

Storing

At room temperature (18 – 25°C) and closed original containers storage life is 6 months.

Partly used containers have always to be closed and the material has to be used up as soon as possible.

Safety measure

Please follow the precaution instructions of the Government Safety Organisation of the chemical industry when working with this material. Please follow safety advices !

Waste Disposal

According to arrangement with local authorities cured material can be disposed as domestic or commercial waste.

Non-cured products are waste which is subject to inspection and has to be disposed accordingly.

In case of further questions please do not hesitate to contact our Department for Product Safety.

The instructions and recommendations are given in good faith and are based on long experience and careful tests. Since the conditions of use are beyond our control, and due to versatility of applications and working methods, we can't give any guarantee. All information are non-binding and are no guarantee for special characteristics or properties of the product. Despite information given from **ebalta** the customer has to make his own tests regarding applications and processing. If any special warranty is requested, written agreement on this subject is essential.

ebalta UK Limited . B2 Langham Park, Trent Lane . Castle Donington . Derbyshire DE74 2UT
t: +44 1332 814700 . f: +44 1332 814775 . e: info@**ebalta**.co.uk . w: www.**ebalta**.co.uk